

2800 SERIES APPLICATION SYSTEMS



Welcome to Centurion™ Wood Coatings

At Centurion™ we believe in proven application systems. They give you the most effective routes to the builds, finishes and dramatic effects you want to create. So on the back of our product sheets we include application systems to help you get to the look you want in record time using Centurion™ Wood Coatings.

For new wood or refinishing (resistant to tannin bleed & dye migration)

- 1 Apply CW-1107 with 15% CW-4002 Catalyst-Hardener at 3-5 wet mils. Let dry overnight/at least 8 hours.
- 2 Catalyze 2800 Series White Poly Topcoat with 15% CW-4002. Apply a minimum of 2 coats at 3-5 wet mils.

For MDF, new wood or refinishing where no tannin or dye blocking is needed

- 1 Apply CW-1107 with 15% CW-4002 at 3-5 wet mils. Let dry for at least 1 hour before sanding.
- 2 Catalyze 2800 Series White with 15% CW-4002. Apply a minimum of 2 coats at 3-5 wet mils.

For high build/grain filling on new wood or refinishing (resistant to tannin bleed & dye migration)

- 1 Apply CW-1107 with 15% CW-4002 at 3-5 wet mils. Let dry overnight/at least 8 hours. Apply a minimum of 2-3 coats at 3-5 wet mils each. Let dry for at least an hour before sanding.
- 2 Catalyze 2800 Series White with 15% CW-4002. Apply a minimum of 2 coats at 3-5 wet mils.

For a self-sealing system using new wood or refinishing

- 1 Apply the 2800 Series White or Clear with 15% catalyst at 3-5 wet mils.
- 2 Catalyze the 2800 Series with 15% catalyst. Apply 1-2 coats at 3-5 wet mils.

Hybrid water-based/solvent-based finishing system

For new wood or refinishing (resistant to tannin bleed & dye migration)

- 1 Apply 1-2 coats of CS-1106 White Vinyl Primer at 2-4 wet mils.
- 2 Catalyze 2800 Series White with 15% catalyst. Apply a minimum of 2 coats at 3-5 wet mils.

Clear hybrid water-based/solvent-based finishing systems

- 1 Apply 1-2 coats of CS-2006 Clear Vinyl Sealer at 2-4 wet mils.
- 2 Catalyze 2800 Series White with 15% catalyst. Apply at a minimum of 2 coats at 3-5 wet mils.

Always follow Technical Data Sheet of each product. Pot life for 2800 series with 15% catalyst is 3 hours. After that, it will thicken, harden and ruin equipment if not cleaned immediately. Be sure to slowly pour catalyst into product while product is under agitation. Make sure all surfaces are clean and sanded with 300 grit to 400 grit between coats.

info@centurionwoodcoatings.com
centurionwoodcoatings.com
Toll-free 877-258-8797